

PURE SOUND

Building a Straight Wire
to the Soul of Music

EVAL2 USER'S GUIDE



1	Introduction	2
1.1	Usage and Purpose.....	2
1.1.1	Setup and operation	2
1.1.2	Power Testing	2
2	EVAL2 Overview	3
3	Interface	4
3.1	Standby switch, S1.....	4
3.2	Power connector, J1.....	4
3.3	Aux connector, J4	4
3.4	Analog input XLR connector, J5.....	5
3.5	Edge connector, J10.....	6
3.6	Speaker output connectors, J11 & J14.....	7
3.7	Gain/Bypass jumpers, J15 & J16	8
4	Power Supplies.....	9
4.1	Linear Regulators.....	9
5	Operating Modes & Status Reporting	10
5.1	Mode Configuration.....	10
5.2	HW Mode.....	10
5.3	SW Model	10
6	Mechanical Specifications & System Considerations	11
6.1	EVAL2 Dimensions	11
6.2	Thermal Requirements.....	12
6.3	Mechanical Requirements	12
6.4	Compliance Testing.....	12
7	External Standby Switch.....	13
8	Revision History	13
	Figure 1 EVAL2 Overview	3
	Figure 2 Buffer Schematic.....	8
	Figure 3 Power Supplies	9
	Figure 4 Mode Selection	10
	Figure 5 Dimensions.....	11
	Figure 6 Back plate mounting holes	12
	Figure 7 External ON/OFF Switch.....	13
	Table 1 Standby switch, S1	4
	Table 2 Power connector, J1.....	4
	Table 3 Aux connector, J3	4
	Table 4 Analog input XLR connector, J5.....	5
	Table 5 Edge Connector, J10	6
	Table 6 Speaker output connectors, J11 & J14.....	7
	Table 7 Speaker output connector options.....	7
	Table 8 Gain/Bypass jumpers, J15 & J16	8
	Table 9 Gain/Bypass resistors, B1 & B2.....	8
	Table 10 Recommended Supply Voltages	9
	Table 11 Mode Selection	10
	Table 12 Revision History.....	13

1 Introduction

This document describes the operation, function and usage of the EVAL2 evaluation kit ("EVM") consisting of one 1ET400A amplifier module and one FE03 front-end module.

1.1 Usage and Purpose

The EVM is provided for engineering evaluation and laboratory test purposes only. Great care should be taken when handling the EVM, especially when connected to power supplies and loads. Observe the voltage and power ratings and apply suitable precautions to protect the operator from electrical hazards.

Also note that the EVM is provided as an unshielded PCB assembly and should be protected from ESD as well as mechanical stress.

1.1.1 Setup and operation

1. Plug 1ET400A module into the Front-End Board (FE03)
2. Place EVM on a flat surface Note that the amplifier base plate is connected to GND and should be attached to an external heatsink, e.g., a larger aluminum plate, for extended high power testing.
3. Connect external laboratory supplies (or other suitable PSU's) to FE03 (refer to section 4)
4. Connect audio input and speaker (or other suitable load/test equipment)
5. Enable operation via toggle-switch on FE03
A red LED will light up when all supply voltages are within operational range.
6. It is recommended to disable operation (toggle-switch) and turn off all power supplies when module is not in use

1.1.2 Power Testing

The amplifier module is protected from overheat via thermal protection system that monitors the temperature of the aluminium base plate. The aluminium plate provides limited cooling, likely adequate for full-power music as well as for typical test sweeps etc., However, for continuous high power delivery additional cooling is required.

2 EVAL2 Overview




Figure 1 EVAL2 Overview

3 Interface

3.1 Standby switch, S1

Position	Description
Towards 1ET400	Operational – Power stage is on
Away from 1ET400	Standby, Power stage is off

Table 1 Standby switch, S1

3.2 Power connector, J1



Pin	Signal	Rating	I/O	Description
1	VDR		P	Gate Drive Supply, referenced to -VP
2	+VP		P	Power Stage Supply, positive rail
3,6	GND		P	Ground
4,5	-VP		P	Power Stage Supply, negative rail

Table 2 Power connector, J1

Connector type equivalent: JST: B06P-VL.

Matching cable part: JST: VLP-06V.

3.3 Aux connector, J4



Pin	Signal	Rating	I/O	Description
1	PSUDIS /AMPON		0 I	PSU off control signal (SW Mode), or Amplifier Disable (HW Mode) – <i>pull low to enable Amp</i>
2	SDA READY		I 0	I2C Data (SW Mode), or Amplifier Ready (HW Mode) – “all good for operation” when high
3	SCL /FATAL		I 0	I2C clock (SW Mode), or Amplifier “error/fail” (HW Mode) – <i>signal goes low on error</i>
4	+5V		P	5V output (from onboard regulator), 20mA max load. Requires R1 mounted
5	+VUNREG		P	Voltage regulator input, positive rail
6	GND		P	Ground
7	-VUNREG		P	Voltage regulator input, negative rail

Table 3 Aux connector, J3

Connector type: JST: B7B-EH-A(LF)(SN).

Matching cable part: JST: EHR-7.

3.4 Analog input XLR connector, J5




Pin	Signal	Rating	I/O	Description
1	GND		-	Ground
2	IN+		I	Analog input, positive
3	IN-		I	Analog input, negative


Table 4 Analog input XLR connector, J5

Connector type: Neutrik NC3FAH2

If a single ended input is need then connect GND and IN- to the negative analog input. When using the FE03 gain stage the single ended input is converted to a fully balanced signal and then fed to the 1ET400 module. The connection of the GND and IN- is best done at the source end.



3.5 Edge connector, J10




Pin	Signal	Rating	I/O	Description
Power Supplies				
1, 2	+VP		P	Power Stage Supply, positive rail
3,4,5 6,7,8	GND		P	Ground
9,10	-VP		P	Power Stage Supply, negative rail
11	VDR		P	Gate Drive Supply, referenced to -VP
12	VD		P	(option use) External Voltage supply to on-board 3.3V regulator
26	+VOP		P	OPAMPs, positive rail
25	-VOP		P	OPAMPs, negative rail
27	GND		P	Ground
I/O's				
13,14,15, 16,18	OUT-		O	Speaker Output, negative (internally connected to GND)
17	VFBLF-		I	Feedback sense input, negative
19	VFBLF+		I	Feedback sense input, positive
20,21,22, 23,24	OUT+		O	Speaker Output, positive
28,33,34	NC		-	Not connected
29	IN+		I	Analog Input, positive
30	IN-		I	Analog Input, negative
31	HS/ADDR		I	Mode/I2C Address Selection; set by one 1% resistor.
32	PSUDIS /AMPON		O I	PSU off control signal (SW Mode), or Amplifier Disable (HW Mode) – <i>pull low to enable Amp</i>
35	SDA READY		I O	I2C Data (SW Mode), or Amplifier Ready (HW Mode) – “all good for operation” when high
36	SCL /FATAL		I O	I2C clock (SW Mode), or Amplifier “error/fail” (HW Mode) – <i>signal goes low on error</i>

Table 5 Edge Connector, J10

Connector type: Samtec: SSW-118-02-T-D-RA

3.6 Speaker output connectors, J11 & J14



Pin	Signal	Rating	I/O	Description
J11_A1	OUT+		0	Speaker output, positive - RED
J13_A1	OUT-		0	Speaker output, negative - BLACK

Table 6 Speaker output connectors, J11 & J14

Connector: 4mm banana socket: Deltron: 571-0100(Black), 571-0500(Red)

The 1ET400A module senses directly at the speaker connector (VFBLF-, VFBLF+) to get lowest possible output impedance, so if the connectors J11 & J14 are removed output signal is sensed through the 1R 0603 resistors at position R7 & R8.

The FE03 has three speaker connection options:




Table 7 Speaker output connector options

Note: For use with a speaker output connector external to the FE03 PCB, the connector’s terminals should each be connected with wires soldered to one or more of the holes indicated above. Remote sense for the feedback to include this extra wiring can be obtained by soldering sense wires to the speaker terminal from the holes indicated. In case the extra external sense wires are not used, this feedback is automatically taken from the PCB through R7 & R8.

3.7 Gain/Bypass jumpers, J15 & J16

FE03 includes a ~13dB pre-gain stage for a total EVM gain of ~26dB. The pre-gain stage can be bypassed by location of two sets of jumpers:



Description	Pre-gain enabled	Pre-gain bypassed
Front-End gain	~14dB	0dB
Total EVM gain	~27dB	~13dB
Jumper setting		

Table 8 Gain/Bypass jumpers, J15 & J16

The pre-gain stage is made with a dual OPA1612 configured as Balanced/single-ended to balanced gain stage as shown below:




Figure 2 Buffer Schematic

Differential input impedance is 10.2kohm

The 0R resistors: R15, R16, R17, R26, R27, R28 are not mounted per default

The gain stage can be enabled/by-passed with the help of pin headed J15/J16 and jumpers as shown in Table 8.

If a fixed setting is needed the 0R resistors can be used as follows:

Description	Pre-gain enabled	Pre-gain bypassed
Front-End gain	~14dB	0dB
Total EVM gain	~27dB	~13dB
Resistors mounted	R16, R17, R26, R27	R15, R28
Resistors NOT mounted	R15, R28	R16, R17, R26, R27
Input Impedance	10.2kohm	4.4kohm

Table 9 Gain/Bypass resistors, B1 & B2

If a different gain is needed resistor R22 can be modified.

$$\text{Gain} = 1 + (R20 + R23) / R22 = 1 + (3.3K + 3.3k) / 1.5K = 5.4 = 14.6dB$$

4 Power Supplies

Refer to below figure showing required power supplies and how to connect these to FE03:




Figure 3 Power Supplies

All supply levels should be crosschecked with the Recommended Operation Conditions as specified in the respective amplifier module data sheet.

Recommended supply voltages for EVAL2 (please also refer to the 1ET400A Data Sheet):

Parameter		Min	Typ	Max	Unit
Power Supplies					
+VP	Power Stage, positive rail voltage	25	65	70	V
-VP	Power Stage, negative rail voltage	-70	-65	-25	V
VDR	Gate Drive, voltage (must be referenced to -VP)	13.6	15	16.5	V
+VUNREG	OPAMPs, positive rail voltage	14.5	15	25	V
-VUNREG	OPAMPs, negative rail voltage	-25	-15	-14.5	V

Table 10 Recommended Supply Voltages

4.1 Linear Regulators

FE03 includes two low noise voltage regulators for the OPAMP’s negative and positive supply voltages (+VOP and -VOP) and a 5V regulator for the standby regulator (+VSBY).

5 Operating Modes & Status Reporting

5.1 Mode Configuration

The EVAL2 can operate in two modes:

1. HW Mode: all control and status via pins (HW interface)– DEFAULT CONFIGUTATION
2. SW Mode: enables control and status via I2C interface

FE03 is configured for HW Mode by default. To reconfigure for SW Mode, at bit of soldering is required, see Table 11 and Figure 4:

FP	Channel	Description	HW Mode	SW Mode
D2	1	Mode Selection	Diode	0Ω shunt
R2	1	I2C Address Selection	open	Refer to 1ET400A data sheet

Table 11 Mode Selection




Figure 4 Mode Selection

5.2 HW Mode

The amplifier modules are controlled via toggle switch S1 connected to amplifier control signal /AMPON. /AMPON is also made available on connectors J4 and can be controlled via external source.

Amplifier status is signaled via READY and /FATAL:

- READY signal is connected to a RED LED on FE03, and is pinned out on connector J4
- /FATAL signal is pinned out on connector: J4.

5.3 SW Model

The main feature of the SW Mode is access via I2C to status and control information. The I2C register map can be found in the amplifier data sheet.

I2C is accessed via SCL, SDA on connectors J2, J3 and J16.

The I2C address can be programmed via value of resistors R2 and R5 on FE03. Refer to the **Mode Selection via HS/ADR** table in the amplifier data sheet for information on resistor value vs. I2C address.

6 Mechanical Specifications & System Considerations

6.1 EVAL2 Dimensions




Figure 5 Dimensions




Figure 6 Back plate mounting holes

Note: Dimensions from bottom mounting plate including the 8mm standoff.

6.2 Thermal Requirements

While 1ET400A has very low idle losses and high overall efficiency, adequate cooling is essential for sustained power delivery. Careful considerations must be given to design the thermal system in order to achieve desired output power specifications.

It is recommended to mount the module on a heatsink, e.g., an adequately design aluminum chassis.

6.3 Mechanical Requirements

Related to mechanical robustness of the end application, it is the reasonability of the system integrator to specify process, materials, locations, etc. for e.g., gluing of critical components which may be required and to prove/document short- and long-term performance and reliability. The system integrator must ensure integrity of mounting method and materials used related to fixation of the module. It is recommended to thoroughly test the final product for robustness against, e.g., shock and vibration.

6.4 Compliance Testing

1ET400A is designed with considerations for compliance of the end application. However, it is the responsibility of the system integrator to ensure any form of design-for-compliance and associated testing/certification which may be required.

7 External Standby Switch

Standby is controlled by the /AMPON signal, that is present on J4,p1.

J4 also have a GND pin, so an external standby switch can be implemented by wiring a switch on J3,p1 to J3,p6.

The FE03 default mode setting is ‘HW-mode’.

A diode and on/off switch can be implemented as shown below (red box).




Figure 7 External ON/OFF Switch

8 Revision History

Rev	Date	Description	ID
(0.1)	2020-08	Pre-release version	KNM
(1.0)	2020-11	First release	KNM
(1.10)	2020-12	Figure 3, corrected to refer to J4	KNM

Table 12 Revision History

1 EVM Use Restrictions and Warnings:

1.1 EVMS ARE NOT FOR USE IN FUNCTIONAL SAFETY AND/OR SAFETY CRITICAL EVALUATIONS, INCLUDING BUT NOT LIMITED TO EVALUATIONS OF LIFE SUPPORT APPLICATIONS. 1.2 User must read and apply the user guide and other available documentation provided by PURIFI ApS regarding the EVM prior to handling or using the EVM. 1.3 Safety-Related Warnings and Restrictions: 1.3.1 User shall operate the EVM within PURIFI ApS's recommended specifications and environmental considerations stated in the specification or other available documentation provided by PURIFI APS, and any other applicable requirements and employ reasonable and customary safeguards. Exceeding the specified performance ratings and specifications (including but not limited to input and output voltage, current, power, and environmental ranges) for the EVM may cause personal injury or death, or property damage. Any loads applied outside of the specified output range may also result in unintended and/or inaccurate operation and/or possible permanent damage to the EVM and/or interface electronics. Please consult the EVM documentation prior to connecting any load to the EVM output. During normal operation, even with the inputs and outputs are kept within the specified allowable ranges, some circuit components may have elevated case temperatures. When working with the EVM, please be aware that the EVM may become very warm. If there is uncertainty as to the ratings and specifications, please contact PURIFI ApS prior to connecting interface electronics including input power and intended loads. 1.3.2 EVMs are intended solely for use by technically qualified, professional electronics experts who are familiar with the dangers and application risks associated with handling electrical mechanical components, systems, and subsystems. User assumes all responsibility and liability for proper and safe handling and use of the EVM by User or its employees, affiliates, contractors or designees. User assumes all responsibility and liability to ensure that any interfaces (electronic and/or mechanical) between the EVM and any human body are designed with suitable isolation and means to safely limit accessible leakage currents to minimize the risk of electrical shock hazard. User assumes all responsibility and liability for any improper or unsafe handling or use of the EVM by User or its employees, affiliates, contractors or designees. 1.4 User assumes all responsibility and liability to determine whether the EVM is subject to any applicable international, federal, state, or local laws and regulations related to User's handling and use of the EVM and, if applicable, User assumes all responsibility and liability for compliance in all respects with such laws and regulations. User assumes all responsibility and liability for proper disposal and recycling of the EVM consistent with all applicable international, federal, state, and local requirements.

2. Accuracy of Information: To the extent PURIFI ApS provides information on function of EVMs, PURIFI ApS attempts to be as accurate as possible. However, PURIFI ApS does not warrant the accuracy of EVM descriptions or other information on its websites as accurate, complete, reliable, current, or error-free.

3. Disclaimers: 3.1 EXCEPT AS SET FORTH ABOVE, EVMs AND ANY WRITTEN EVM MATERIALS PROVIDED WITH THE EVM (AND THE DESIGN OF THE EVM ITSELF) ARE PROVIDED "AS IS". PURIFI APS DISCLAIMS ALL WARRANTIES, EXPRESS OR IMPLIED, REGARDING TO E.G. BUT NOT LIMITED TO ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE OR NON-INFRINGEMENT OF ANY THIRD PARTY INTELLECTUAL PROPERTY RIGHTS. 3.2 EXCEPT FOR THE LIMITED RIGHT TO USE THE EVM SET FORTH HEREIN, NOTHING IN THESE TERMS AND CONDITIONS SHALL BE CONSTRUED AS GRANTING OR CONFERRING ANY RIGHTS BY LICENSE, PATENT, OR ANY OTHER INDUSTRIAL OR INTELLECTUAL PROPERTY RIGHT OF PURIFI APS, ITS SUPPLIERS/LICENSORS OR ANY OTHER THIRD PARTY, TO USE THE EVM IN ANY FINISHED END-USER OR READY-TO-USE FINAL PRODUCT, OR FOR ANY INVENTION, DISCOVERY OR IMPROVEMENT MADE, CONCEIVED OR ACQUIRED PRIOR TO OR AFTER DELIVERY OF THE EVM.

4. USER'S INDEMNITY OBLIGATIONS AND REPRESENTATIONS. USER WILL DEFEND, INDEMNIFY AND HOLD PURIFI APS, ITS LICENSORS AND THEIR REPRESENTATIVES HARMLESS FROM AND AGAINST ANY AND ALL CLAIMS, DAMAGES, LOSSES, EXPENSES, COSTS AND LIABILITIES (COLLECTIVELY, "CLAIMS") ARISING OUT OF OR IN CONNECTION WITH ANY HANDLING OR USE OF THE EVM THAT IS NOT IN ACCORDANCE WITH THESE TERMS AND CONDITIONS. THIS OBLIGATION SHALL APPLY WHETHER CLAIMS ARISE UNDER STATUTE, REGULATION, OR LAW OF TORT, CONTRACT OR ANY OTHER LAW, AND EVEN IF THE EVM FAILS TO PERFORM AS DESCRIBED OR EXPECTED.

5. Limitations on Damages and Liability: 5.1 General Limitations. IN NO EVENT SHALL PURIFI APS BE LIABLE FOR ANY SPECIAL, COLLATERAL, INDIRECT, PUNITIVE, INCIDENTAL, CONSEQUENTIAL, OR EXEMPLARY DAMAGES IN CONNECTION WITH OR ARISING OUT OF THESE TERMS AND CONDITIONS OR THE USE OF THE EVMS PROVIDED HEREUNDER, REGARDLESS OF WHETHER PURIFI APS HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. EXCLUDED DAMAGES INCLUDE, BUT ARE NOT LIMITED TO, COST OF REMOVAL OR REINSTALLATION, ANCILLARY COSTS TO THE PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES, RETESTING, OUTSIDE COMPUTER TIME, LABOR COSTS, LOSS OF GOODWILL, LOSS OF PROFITS, LOSS OF SAVINGS, LOSS OF USE, LOSS OF DATA, OR BUSINESS INTERRUPTION. NO CLAIM, SUIT OR ACTION SHALL BE BROUGHT AGAINST PURIFI APS MORE THAN ONE YEAR AFTER THE RELATED INCIDENCE HAS OCCURRED.

5.2 Specific Limitations. IN NO EVENT SHALL PURIFI APS'S AGGREGATE LIABILITY FROM ANY WARRANTY OR OTHER OBLIGATION ARISING OUT OF OR IN CONNECTION WITH THESE TERMS AND CONDITIONS, OR ANY USE OF ANY PURIFI APS EVM PROVIDED HEREUNDER, EXCEED THE TOTAL AMOUNT PAID TO PURIFI APS FOR THE PARTICULAR UNITS SOLD UNDER THESE TERMS AND CONDITIONS WITH RESPECT TO WHICH LOSSES OR DAMAGES ARE CLAIMED. THE EXISTENCE OF MORE THAN ONE CLAIM AGAINST THE PARTICULAR UNITS SOLD TO USER UNDER THESE TERMS AND CONDITIONS SHALL NOT ENLARGE OR EXTEND THIS LIMIT.

6. Governing Law: These terms and conditions shall be governed by and interpreted in accordance with the laws of Denmark, excluding Denmark's conflict-of-law rules, leading to the use of other law than the laws of Denmark. User agrees that non-exclusive jurisdiction for any dispute arising out of or relating to these terms and conditions lies within the courts of Denmark and consents to venue in Copenhagen, Denmark. Notwithstanding the foregoing, any judgment may be enforced in Danish court, and PURIFI ApS may seek injunctive relief in Denmark or foreign countries.